CONTRACTORS SERIES BLAST MACHINE **4 & 6 CU. FT. WITH MILLENNIUM ELECTRIC** PRESSURE RELEASE REMOTE CONTROLS 0. M. 22559

MC FILE NUMBER: 2078/0699 DATE OF ISSUE: 06/99 REVISION: E, 02/06



A WARNING

Do not proceed with these instructions until you have READ the preface of this MANUAL and YOU **UNDERSTAND** its contents. These **WARNINGS** are included for the health and safety of the operator and those in the immediate vicinity. Keep this manual for future reference.

© 2006 CLEMCO INDUSTRIES CORP. One Cable Car Dr. Washington, MO 63090 Phone (636) 239-4300 Fax (800) 726-7559 Email: info@clemcoindustries.com www.clemcoindustries.com



A WARNING

- Read and follow ALL instructions before using this equipment.
- Failure to comply with ALL instructions can result in serious injury or death.
- In the event that the user, or any assistants of the user of this equipment cannot read or cannot completely understand the warnings and information contained in these instructions, the employer of the user and his assistants must thoroughly educate and train them on the proper operation and safety procedures of this equipment.

NOTICE TO PURCHASERS AND USERS OF OUR PRODUCTS AND THIS INFORMATIONAL MATERIAL

The products described in this material, and the information relating to those products, is intended for knowledgeable, experienced users of abrasive blasting equipment.

No representation is intended or made as to the suitability of the products described herein for any particular purpose or application. No representations are intended or made as to the efficiency, production rate, or the useful life of the products described herein. Any estimate regarding production rates or production finishes are the responsibility of the user and must be derived solely from the user's experience and expertise, and must not be based on information in this material.

The products described in this material may be combined by the user in a variety of ways for purposes determined solely by the user. No representations are intended or made as to the suitability or engineering balance of the combination of products determined by the user in his selection, nor as to the compliance with regulations or standard practice of such combinations of components or products.

Abrasive Blast Equipment is only a component of the range of equipment used in an abrasive blasting job. Other products may include an air compressor, abrasive, scaffolding, hydraulic work platforms or booms, paint spray equipment, dehumidification equipment, air filters and receivers, lights, ventilation equipment, parts handling equipment, specialized respirators, or equipment that while offered by Clemco may have been supplied by others. Each manufacturer and supplier of the other products used in the abrasive blasting job must be contacted for information, training, instruction and warnings with regard to the proper and safe use of their equipment in the particular application for which the equipment is being used. The information provided by Clemco is intended to provide instruction only on Clemco products. All operators must be trained in the proper, safe, use of this equipment. It is the responsibility of the users to familiarize themselves with, and comply with, all appropriate laws, regulations, and safe practices that apply to the use of these products. Consult with your employer about training programs and materials that are available.

Our company is proud to provide a variety of products to the abrasive blasting industry, and we have confidence that the professionals in our industry will utilize their knowledge and expertise in the safe efficient use of these products.

GENERAL INSTRUCTIONS

Described herein are some, BUT NOT ALL, of the major requirements for safe and productive use of blast machines, remote control systems, operator respirator assemblies, and related accessories. Completely read ALL instruction manuals prior to using equipment.

The user's work environment may include certain HAZARDS related to the abrasive blasting operation. Proper protection for the blaster, as well as anyone else that may be EXPOSED to the hazards generated by the blasting process, is the responsibility of the user and/or the employer. Operators MUST consult with their employer about what hazards may be present in the work environment including, but not limited to, exposure to dust that may contain TOXIC MATERIALS due to the presence of silica, cyanide, arsenic or other toxins in the abrasive, or materials present in the surface to be blasted such as lead or heavy metals in coatings. The environment may also include fumes that may be present from adjacent coatings application, contaminated water, engine exhaust, chemicals, and asbestos. The work area may include PHYSICAL HAZARDS such as an uneven work surface. poor visibility, excess noise, and electrical hazards. The operator MUST consult with his employer on the identification of potential hazards, and the appropriate measures that MUST be taken to protect the blaster and others that might be exposed to these hazards.

ALL machines, components and accessories MUST be installed, tested, operated and maintained only by trained, knowledgeable, experienced users.

DO NOT modify or substitute any Clemco parts with other types or brands of equipment. Unauthorized modification and parts substitution on supplied air respirators is a violation of OSHA regulations and voids the NIOSH approval.

OPERATIONAL INSTRUCTIONS

OPERATOR SAFETY EQUIPMENT

A WARNING

- Blast operators and others working in the vicinity of abrasive blasting must always wear properlymaintained, NIOSH-approved, respiratory protection appropriate for the job site hazards.
- DO NOT USE abrasives containing more than one percent crystalline (free) silica. Ref. NIOSH Alert #92-102
- Inhalation of toxic dust (crystalline silica, asbestos, lead paint and other toxins) can lead to serious or fatal disease (silicosis, asbestosis, lead or other poisoning).
- ALWAYS wear NIOSH-approved supplied-air respirators as required by OSHA, in the presence of any dust including, but not limited to, handling or loading abrasive; blasting or working in the vicinity of blast jobs; and cleanup of expended

abrasive. Prior to removing respirator, an air monitoring instrument should be used to determine when surrounding atmosphere is clear of dust and safe to breathe.

- NIOSH-approved, supplied-air respirators are to be worn ONLY in atmospheres:
 - NOT IMMEDIATELY dangerous to life or health and,
 - from which a user can escape WITHOUT using the respirator.
- Clemco supplied-air respirators DO NOT REMOVE OR PROTECT AGAINST CARBON MONOXIDE (CO) OR ANY OTHER TOXIC GAS. Carbon monoxide and toxic gas removal and/or monitoring device must be used in conjunction with respirator to insure safe breathing air.
- Air supplied to respirator MUST BE AT LEAST GRADE D QUALITY as described in Compressed Gas Association Commodity Specification G-7.1, and as specified by OSHA Regulation 1910.139 (d).
- ALWAYS locate compressors to prevent contaminated air (such as CO from engine exhaust) from entering the air intake system. A suitable in-line air purifying sorbent bed and filter or CO Monitor should be installed to assure breathing air quality.
- ALWAYS use a NIOSH-approved breathing air hose to connect an appropriate air filter to the respirator. Use of a nonapproved air hose can subject the operator to illness caused by the release of chemical agents used in the manufacture of nonapproved breathing air hose.
- ALWAYS check to make sure air filter and respirator system hoses are NOT CONNECTED to in-plant lines that contain nitrogen, acetylene or any other non-breathable gas. NEVER use oxygen with air line respirators. NEVER modify air line connections to accommodate air filter/respirator breathing hose WITHOUT FIRST testing content of the air line. FAILURE TO TEST THE AIR LINE MAY RESULT IN DEATH TO THE RESPIRATOR USER.
- Respirator lenses are designed to protect against rebounding abrasive. They do not protect against flying objects, glare, liquids, radiation or high speed heavy materials.
 Substitute lenses from sources other than the original respirator manufacturer will void NIOSH-approval of this respirator.

BLAST MACHINES AND REMOTE CONTROLS

▲ WARNING

- ALWAYS equip abrasive blast machines with remote controls.
- Abrasive blast machine operators must wear NIOSHapproved supplied-air respirators (ref: OSHA regulations 1910.94, 1910.132, 1910.139 and 1910.244).
- NEVER modify OR substitute remote control parts. Parts from different manufacturers are NOT compatible with Clemco

- equipment. If controls are altered, involuntary activation, which may cause serious injury, can occur.
- Inspect the air control orifice DAILY for cleanliness.
 NEVER use welding hose in place of twinline control hose. The internal diameter and rubber composition are UNSAFE for remote control use.
- UNLESS OTHERWISE SPECIFIED, maximum working pressure of blast machines and related components MUST NOT exceed National Board approved 125 psig (8.5 BAR).
- NEVER weld on blast machine. Welding may affect dimensional integrity of steel wall and WILL VOID National Board approval.
- Point nozzle ONLY at structure being blasted. High velocity abrasive particles WILL inflict serious injury. Keep unprotected workers OUT of blast area.
- NEVER attempt to manually move blast machine when it contains abrasive. EMPTY machines, up to 6 cu. ft.(270kg) capacity, are designed to be moved:
- on flat, smooth surfaces by AT LEAST two people;
- with the Clemco "Mule"; or
- with other specially designed machine moving devices.
- Larger empty blast machines or ANY blast machine containing abrasive MUST be transported by mechanical lifting equipment.

AIR HOSE, BLAST HOSE, COUPLINGS, AND NOZZLE HOLDERS

- Air hose, air hose fittings and connectors at compressors and blast machines MUST be FOUR times the size of the nozzle orifice. Air hose lengths MUST be kept as short as possible AND in a straight line. Inspect DAILY and repair leakage IMMEDIATELY.
- Blast hose inside diameter MUST be THREE to FOUR times the size of the nozzle orifice. AVOID sharp bends that wear out hose rapidly. Use SHORTEST hose lengths possible to reduce pressure loss. Check blast hose DAILY for soft spots. Repair or replace IMMEDIATELY.
- ALWAYS cut loose hose ends square when installing hose couplings and nozzle holders to allow uniform fit of hose to coupling shoulder. NEVER install couplings or nozzle holders that DO NOT provide a TIGHT fit on hose. ALWAYS use manufacturers recommended coupling screws.
- Replace coupling gaskets FREQUENTLY to prevent leakage. Abrasive leakage can result in dangerous coupling failure. ALL gaskets MUST be checked SEVERAL times during a working day for wear, distortion and softness.
- Install safety pins at EVERY coupling connection to prevent accidental disengagement during hose movement.
- ALWAYS attach safety cables at ALL air hose AND blast hose coupling connections. Cables relieve tension on hose and control whipping action in the event of a coupling blow-out.

MAINTENANCE

- ALWAYS shut off compressor and depressurize blast machine BEFORE doing ANY maintenance.
- Always check and clean ALL filters, screens and alarm systems when doing any maintenance.
- ALWAYS cage springs BEFORE disassembling valves IF spring-loaded abrasive control valves are used.
- ALWAYS completely follow owner's manual instructions and maintain equipment at RECOMMENDED intervals.

ADDITIONAL ASSISTANCE

- Training and Educational Programs.
 Clemco Industries Corp. offers a booklet, Blast-Off 2, developed to educate personnel on abrasive blast equipment function and surface preparation techniques. Readers will learn safe and productive use of machines, components and various accessories, including selection of abrasive materials for specific surface profiles and degrees of cleanliness.
- The Society for Protective Coatings (SSPC) offers a video training series on protective coatings including one entitled "Surface Preparation." For loan or purchase information, contact SSPC at the address shown below.

TECHNICAL DATA AND RESEARCH COMMITTEES

 The following associations offer information, materials and videos relating to abrasive blasting and safe operating practices.

The Society for Protective Coatings (SSPC)

40 24th Street, Pittsburgh PA 15222-4643 Phone: (412) 281-2331 • FAX (412) 281-9992 Email: research@sspc.org • Website: www.sspc.org

National Association of Corrosion Engineers (NACE)

1440 South Creek Drive, Houston TX 77084 Phone: (281) 228-6200 • FAX (281) 228-6300 Email: msd@mail.nace.org • Website: www.nace.org

American Society for Testing and Materials (ASTM)

100 Barr Harbor Dr., West Conshohocken, PA 19428 Phone (610) 832-9500 • FAX (610) 832-9555 Email: service@astm.org • Website: www.astm.org

NOTICE

This equipment is not intended to be used in an area that might be considered a hazardous location as described in the National Electric Code NFPA 70 1996, article 500.

WARRANTY

The following is in lieu of all warranties express, implied or statutory and in no event shall seller or its agents, successors, nominees or assignees, or either, be liable for special or consequential damage arising out of a breach of warranty. This warranty does not apply to any damage or defect resulting from negligent or improper assembly or use of any item by the buyer or its agent or from alteration or attempted repair by any person other than an authorized agent of seller. All used, repaired, modified or altered items are purchased "as is" and with all faults. In no event shall seller be liable for consequential or incidental damages. The sole and exclusive remedy of buyer for breach of warranty by seller shall be repair or replacement of defective parts or, at seller's option, refund of the purchase

price, as set forth below:

- 1.Seller makes no warranty with respect to products used other than in accordance hereunder.
- 2.On products seller manufactures, seller warrants that all products are to be free from defects in workmanship and materials for a period of one year from date of shipment to buyer, but no warranty is made that the products are fit for a particular purpose.
- 3.On products which seller buys and resells pursuant to this order, seller warrants that the products shall carry the then standard warranties of the manufacturers thereof, a copy of which shall be made available to customer upon request.
- 4.The use of any sample or model in connection with this order is for illustrative purposes only and is not to be construed as a warranty that the product will conform to the sample or model.
 5.Seller makes no warranty that the products are delivered free of the rightful claim of any third party by way of patent infringement or the like.
- 6. This warranty is conditioned upon seller's receipt within ten (10) days after a buyer's discovery of a defect, of a written notice stating in what specific material respects the product failed to meet this warranty. If such notice is timely given, seller will, at its option, either modify the product or part to correct the defect, replace the product or part with complying products or parts, or refund the amount paid for the defective product, any one of which will constitute the sole liability of seller and a full settlement of all claims. No allowance will be made for alterations or repairs made by other than those authorized by seller without the prior written consent of seller. Buyer shall afford seller prompt and reasonable opportunity to inspect the products for which any claim is made as above stated.

Except as expressly set forth above, all warranties, express, implied or statutory, including implied warranty of merchantability, are hereby disclaimed.

DAILY SET-UP CHECK LIST


A WARNING

- ALL piping, fittings and hoses MUST be checked DAILY for tightness and leakage.
- ALL equipment and components MUST be thoroughly checked for wear.
- ALL worn or suspicious parts MUST be replaced.
- ALL blast operators MUST be properly trained to operate equipment.
- ALL blast operators MUST be properly outfitted with abrasive resistant clothing, safety shoes, leather gloves and ear protection.
- BEFORE blasting ALWAYS use the following check list.

☐ 1. PROPERLY MAINTAINED AIR COMPRESSOR size	d
to provide sufficient volume (cfm) for nozzle and other tools PLUS a 50% reserve to allow for nozzle wear. Use large compressor outlet and large air hose (4 times the nozzle orifisize). FOLLOW MANUFACTURERS MAINTENANCE INSTRUCTIONS.	ce

☐ 2. BREATHING AIR COMPRESSOR (oil-less air pump) capable of providing Grade D Quality air located in a dust free, contaminant free area. If oil-lubricated air compressor is used to supply respirator, it should have high temperature monitor and CO monitor or both. If CO monitor is not used, air MUST

be tested FREQUENTLY to ensure proper air quality. ■ 8. BLAST HOSE with ID 3 to 4 times the nozzle orifice. Lines MUST be run AS STRAIGHT AS POSSIBLE from ☐ 3. Clean, properly maintained NIOSH-APPROVED machine to work area with NO sharp bends. Check DAILY for SUPPLIED-AIR RESPIRATOR. ALL components should internal wear and external damage. ALWAYS be present. NEVER operate without inner lens in place. Thoroughly inspect ALL components DAILY for 9. HOSE COUPLINGS. NOZZLE HOLDERS fitted cleanliness and wear. ANY substitution of parts voids NIOSH SNUGLY to hose end and installed using PROPER coupling approval i.e. cape, lenses, breathing hose, breathing air supply hose, air control valve, cool air or climate control devices. screws. Coupling lugs MUST be snapped FIRMLY into locking position. Gasket MUST form positive seal with safety pins inserted through pin holes. Check gaskets and replace if ANY 4. OSHA required BREATHING AIR FILTER for removal sign of wear, softness or distortion. ALWAYS install safety of moisture and particulate matter from breathing air supply. cables at every connection to prevent disengagement. Check THIS DEVICE DOES NOT REMOVE OR DETECT CARBON nozzle holder for worn threads. NEVER MIX DIFFERENT BRANDS OF COMPONENTS. Check each of these MONOXIDE (CO). ALWAYS USE CO MONITOR ALARM. components DAILY. 5. ASME CODED BLAST MACHINE sized to hold 1/2 ☐ 10. Inspect NOZZLE and GASKET DAILY for wear. hour abrasive supply. ALWAYS ground machine to eliminate static electricity hazard. Examine pop up valve for alignment. Replace nozzle when 1/16" larger than original size or if liner appears cracked. Check nozzle threads for wear. Blast machine MUST be fitted with a screen to keep out foreign objects and a cover to prevent entry of moisture overnight. 11. Use abrasive that is properly sized and free of harmful ☐ 6. AIR LINE FILTER installed AS CLOSE AS POSSIBLE substances; such as, free silica, cyanide, arsenic or lead. to machine inlet. Sized to match inlet piping or larger air supply Check material data sheet for presence of toxic or harmful line. Clean filter DAILY. Drain OFTEN. substances. 7. REMOTE CONTROLS MUST be in PERFECT 12. Test surface to be blasted for toxic substances. Take operating condition. ONLY use APPROVED spare parts, appropriate, and NIOSH required, protective measures for including twin- line hose. DAILY: test system operation and operator and bystanders which pertain to substances found on check button bumper and spring action of lever and lever lock. the surface to be blasted. DO NOT USE WELDING HOSE.



CONTRACTOR SERIES BLAST MACHINE, 4 & 6 CU. FT. WITH MILLENNIUM ELECTRIC, PRESSURE RELEASE REMOTE CONTROLS

1.0 INTRODUCTION

1.1 Scope of manual

1.1.1 These instructions cover the set-up, operation, maintenance, troubleshooting, and replacement parts for the following Clemco Contractor Series Blast machines with Millennium Electric Remote Controls.

20" diameter, 4 cu. ft. capacity 24" diameter, 6 cu. ft. capacity

- 1.1.2 These instructions also contain important information required for safe operation of the machine. All blast operator(s) and machine (pot) tenders must be trained in the safe operation of the blast machine, remote control system, and all blasting accessories. Before using the machine, all personnel involved with the blast machine operation must read this entire manual, including the orange cover, and all accessory manuals.
- 1.1.3 All personnel involved with the abrasive blasting process must be made aware of the hazards associated with abrasive blasting. The Clemco booklet "Abrasive Blasting Safety Practices" is included with every blast machine, and contains important safety information about abrasive blasting that may not be included in equipment operation manuals. Additional copies are available from Clemco Industries.

1.2 Safety Alerts

1.2.1 Clemco uses safety alert signal words, based on ANSI Z535.4-1998, to alert the user of a potentially hazardous situation that may be encountered while operating this equipment. ANSI's definitions of the signal words are as follows:



This is the safety alert symbol. It is used to alert the user of this equipment of potential personal injury hazards.

Obey all safety messages that follow this symbol to avoid possible injury or death.

CAUTION

Caution used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.

A CAUTION

Caution indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

A WARNING

Warning indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

A DANGER

Danger indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

1.3 Components and Operating Principles

1.3.1 Components

1.3.1.1 The primary components of the Contractor machines are shown in Figure 1. They include the blast machine with Millennium Remote Controls, electric control panel, Quantum Abrasive Metering Valve, frame assembly, optional air filter, and optional CPF air filter.

1.3.2 Instruction Maintenance Manuals

1.3.2.1 Individual manuals are included with the following optional accessories:

CPF Air Filter Apollo Respirator Cool Air Tube

1.3.2.2 The front leg contains a storage area for owners manuals. After reviewing all the manuals, and start-up and adjustments are completed, remove the urethane cover plate and store manuals in the compartment, for future reference.

1.3.3 Blast Machine

1.3.3.1 Clemco blast machines (pressure vessels) are manufactured to American Society of Mechanical Engineers (ASME) standards, as described in Section VII, Div. 1, and carry a National Board certification. It is

CONTRACTOR SERIES BLAST MACHINE, 4 & 6 CU. FT. WITH MILLENNIUM ELECTRIC, PRESSURE RELEASE REMOTE CONTROLS

the owner's responsibility to maintain the integrity of the vessel as may be required by some states. This may include regular inspection and hydrostatic testing as described in National Board Inspection Code and Jurisdictional Regulations and /or Laws.

A WARNING

Welding, grinding, or drilling on the blast machine could weaken the vessel. Compressed air pressure could cause a weakened blast machine to rupture, resulting in death or serious injury. Welding, grinding, or drilling on the blast machine vessel, without a National Board "R" stamp voids the ASME and National Board certification.


1.3.3.2 All welding repairs done on the vessel must be performed by certified welders, at shops holding a National Board "R" Stamp. Welding performed by any welder not properly qualified per the ASME Code voids ASME and National Board certification of the vessel.

1.3.3.3 This blast machine is rated for a maximum of 150 psi (pounds per square inch); do not exceed the rated pressure.

A WARNING

Excessive air pressure could cause a blast machine to rupture. To prevent serious injury or death, do not exceed the rated pressure of the blast machine vessel.

1.3.3.4 Use lifting eyes to assist in loading and unloading the blast machine. Do not use a sling around the cart handles or piping.



CONTRACTOR SERIES BLAST MACHINE, 4 & 6 CU. FT. WITH MILLENNIUM ELECTRIC, PRESSURE RELEASE REMOTE CONTROLS

- **1.3.3.5** The blast machine is equipped with remote controls that allow the operator to pressurize the machine to start blasting, and depressurize it to stop blasting, at the nozzle.
- 1.3.3.6 OSHA does not require pressure relief valves on blast machines when air compressors supplying air to the blast machines are built to ASME (1) specifications and comply with OSHA (2) regulations. ASME Manual section VIII, Division 1, UG-125, paragraph A90 (g) states that pressure relief valves or protective devices "...need not be installed directly on a pressure vessel when the source of pressure is external to the vessel and is under such positive control that the pressure in the vessel cannot exceed the maximum allowable working pressure at the operating temperature...". OSHA regulation 1910.169 refers to the above ASME code when describing the necessity of pressure relief valves on compressed air equipment. DO NOT operate blast machines with air compressors that are not equipped with properly functioning pressure relief valves.
- ⁽¹⁾ American Society of Mechanical Engineers, Boiler and Pressure Vessel Code, 1989
- (2) Occupational Safety and Health Administration, 29 CFR 1910, Subpart M - Compressed Gas and Compressed Air Equipment.

1.3.4 Remote Controls


- **1.3.4.1** The components of the Millennium electric remote control system are shown in Figure 2. They include the Millennium Valve, RLX Control Handle, 50-foot control cord, 4-foot long twinline control hoses, and all necessary fittings
- 1.3.4.2 The remote control system is an OSHA-required safety device. The control handle, located near the blast nozzle, is the activator for the remote control system. When the operator intentionally or unintentionally removes hand-held pressure from the remote control handle, the machine depressurizes, stopping air and abrasive flow through the nozzle. The remote control system "fails to safe", which means any interruption in the electro-pneumatic control circuit for any reasons such as a break in the cord, the compressor stops running, or the operator drops the blast hose, the remote controls deactivate the blast machine.

A WARNING

Never modify or substitute remote control parts. Parts from other manufacturers are not compatible with Clemco equipment. If ANY part of the remote control system is altered, involuntary activation, which may cause serious injury, can occur.

- **1.3.4.3** Millennium Remote Controls are pressure-release-style systems, which control the pressurization and depressurization of the blast machine. Pressurization, which starts blasting, occurs when the control handle is pressed. Depressurization, which stops blasting, occurs when the handle is released.
- 1.3.4.4 Millennium Electric Remote Controls operate electro-pneumatically on the "return air" principle. When the control handle lever is up, control air from the blast machine travels to the control box and stops. As long as air does not pass through the box, the remote control system remains inactive. From the box, a 12-volt electrical current is sent through the control cord to a switch mounted under the control handle lever. When the control handle lever is pressed, it makes contact with the switch, which engages solenoid in the control box to permit air to pass through the box to open the inlet segment and close the outlet segment of the Millennium valve. This pressurizes the blast machine, which starts the blasting. When the handle lever is released, it immediately exhausts control air at the panel, which closes the inlet segment, and opens the outlet segment to depressurize the machine and stop the blasting.
- **1.3.4.5** Electric remote controls are used when the nozzle is farther than 100 feet from the blast machine. At that distance pressure drop and actuation time of pneumatic systems may be too great to ensure fast, safe operation. Electric systems are also used in cold weather, when moisture in the air supply of pneumatic systems may freeze and cause the remote controls to fail. For that reason an antifreeze injector is installed on all electric remote control panels.

NOTE: The maximum recommended total length of control cord is 300 feet. Distances greater than 300 feet offer too much electrical resistance, and may cause the controls to malfunction. If an application requires greater distance, cord with larger diameter wire must be provided by the user.



Air Filter, Optional 1.3.5

1.3.5.1 The optional filter removes particles and condensed moisture from the compressed air before it enters the machine. Water is drained by use of a manual drain located at the bottom of the filter.

Frame and Cart 1.3.6

1.3.6.1 The frame assembly provides added protection for the piping, valves and accessories. This protection keeps the piping aligned and tight. The wheeled cart assists in the mobility of the machine over smooth flat surfaces. See transporting and moving in Section 3.1.

2.0 **INITIAL SET-UP**

Control Panel, Ref. Figure 2 2.1

WARNING

Do not use 120-volt AC systems for outdoor blasting, or in any application that exposes the control circuit, control panel or power cord to water. Use 12-volt DC controls for those applications. Ignoring this warning could cause electrical shock and possible death.

- 2.1.1 Attach the 4-foot twinline hose to the two fittings on the Millennium valve. Either side of the hose can be attached to either fitting.
- Attach the free end of the side of the twinline that connects to the orifice fitting, to the fitting on the air filter mounted on the control panel.
- Attach the free end on the other side of the twinline hose (shown as "Return line" in Figure 2) to the fitting on the bottom of the control panel marked "Air Valve".

CONTRACTOR SERIES BLAST MACHINE, 4 & 6 CU. FT. WITH MILLENNIUM ELECTRIC, PRESSURE RELEASE REMOTE CONTROLS

- **2.1.4** Attach one end of the 5-foot single line hose to the fitting on the bottom of the control panel marked "Grit Valve". Connect the other end to the fitting on the Quantum metering valve.
- 2.2 Blast Hose and Control Cord Connections, See Figure 2.

WARNING


Where two or more blast machines are used, care must be taken when tracing and connecting control lines, control cord, and blast hose. Cross-connecting control lines or blast hose could lead to serious injury, death, or property damage from unintentional actuation of a blast machine. To prevent cross connecting blast hose and control cords, the cord and hose should be of equal lengths, and the hose, cord, and blast machine couplings clearly marked. Use the optional hose identification kits, part no. 15890 for use with two blast machines, or part no. 15891 for up to four machines, to mark each hose, cord, and corresponding connection per the instructions supplied with the kit. Carefully trace and verify each connection before operating.

- **2.2.1** Uncoil the blast hose, and lay the 50-foot control cord alongside it. When additional hoses are connected, the hose and cord should be of equal lengths.
- **2.2.2** Band the control handle to the blast hose close to the nozzle holder, using the two nylon ties provided. Once the control is firmly attached, clip the tie ends so they will not snag the operator's clothing or interfere with the operation of the control handle.
- **2.2.3** Wrap the whip cord from the electric control handle once around the blast hose, as shown in Figure 3, and then connect it to the control cord. If the cord is not wrapped as described, when the hose bends excessive strain will cause the wires to pull out of the connectors or electric switch.

2.2.4 Band the cord to the hose on both sides of the cord connections, as shown in Figure 3.

CAUTION

Provide enough slack at all cord connections to prevent the cord from pulling out of the connectors when the blast hose is pulled or dragged. Band the cord to the blast hose on both sides of all connections.



- **2.2.5** Band the cord to the blast hose every 4 to 6 feet. Also, band the cord on both sides of each electrical connection.
- **2.2.6** Place the nozzle washer in the nozzle holder, and screw the nozzle into the holder. The nozzle must seat tightly against the nozzle washer.

2.3 Compressed-Air Supply Hose Connection

2.3.1 Install an air supply hose fitting to the optional air filter or air inlet, that is compatible with the compressed-air supply hose from the compressor. See Section 3.2.2.

2.4 Breathing Air Connections, optional CPF Filter

A WARNING

Air supply to the respirator system is critical to the safety of the user. Read the CPF Filter and Apollo Respirator manuals carefully. Poor quality air will cause serious respiratory injury or death to the user.

2.4.1 Breathing air must meet the requirements for Grade D or higher quality, as described in Compressed Gas Association Commodity Specification pamphlet G-7.1., titled Commodity Specification For Air, Published by Compressed Gas Association Inc., Chantilly, VA. (CFR Title 30 Chapter 1).

A DANGER

Do not connect the CPF Filter, or any other regulator or filter, to bottled air or any other air source that does not have a pressure reducing valve that reduces pressure to maximum of 150 psi. Failure to comply with this warning will cause low pressure devices to explode under the high pressure of bottled air. Such an explosion could cause severe injury or death.

- **2.4.2** Connect an air supply hose fitting that is compatible with the air supply hose from an air source that meets OSHA requirements for respirable air, to the CPF Filter inlet, as shown in Figure 1. Pressure supplied to the filter must not exceed 150 psi.
- **2.4.3** For models with CPF filter only, connect the respirator lead hose to the compatible fitting on the CPF filter. Refer to the Apollo Respirator and CPF Filter manuals for instructions concerning their operation.

- 3.0 OPERATION
- 3.1 Transporting and Moving
- 3.1.1 Transporting a blast machine

A WARNING

- Always empty the blast machine before lifting or hoisting.
- Use the lifting eyes when lifting the machine. Never hoist the machine by the handle or piping, or with a sling through the handle or piping.
- Always use lift equipment that is rated higher than the weight of the machine and accessories.
- When transporting a machine on a pallet, always securely attach the machine to a sturdy pallet.
- Always securely anchor the machine to the transport vehicle.
- Anyone using material handling equipment to move, transport, or lift the machine must be experienced, and able to recognize and avoid hazards associated with handling this type of machinery, and to safely operate the equipment.
- Failure to observe these warnings could result in serious injury or death.
- **3.1.1.1** Always empty the machine before transporting. Transporting the machine containing abrasive could increase the weight to an unsafe handling limit, and could cause abrasive to settle in piping.

3.1.2 Moving a blast machine

WARNING

Never attempt to manually move a blast machine when it contains abrasive. An empty machine may be moved when the following criteria are met:

3.1.2.1 An empty machine may be moved manually, on level flat surfaces.

WARNING

Do not manually move the machine on an incline, or on a slippery or irregular surface that could cause the operator to slip or lose balance. Sudden weight shifts when the machine is tilted on an incline, and slipping or tripping while moving the machine will cause the operator to lose control of the machine, causing severe injury and property damage.

- **3.1.2.2** Move the machine by pushing it forward. Do not back-up while moving the machine, as potential tripping hazards would not be seen.
- **3.1.2.3** Use the lifting eyes when lifting the machine. Do not use a sling around the cart handles or piping.
- **3.1.2.4** If the machine contains any abrasive, keep the machine upright. Laying down a machine containing abrasive could cause abrasive to lodge in the piping and cause the machine to malfunction, or damage valves.

3.2 Start-Up

- **3.2.1** Locate the compressor upwind from the blasting operation to prevent contaminated air from entering the compressor intake.
- **3.2.2** Connect an air line from the compressor to the air supply hose connector installed on the blast machine inlet. For best blasting performance, use 1-1/4" ID or larger air line when using up to a 5/16" orifice nozzle, 1-1/2" or larger when using up to a 3/8" nozzle, and 2" or larger when using up to a 1/2" nozzle. See the compressed air and abrasive consumption chart in Figure 4 for approximate air consumption.
- **3.2.3** Make sure the coupling gaskets are in place and in good condition before connecting the blast hose to the quick coupling on the blast machine. When connecting the hose make sure the coupling spring lock pins are at 180 degrees (Pins should enter the unused hole of the adjoining coupling). The spring lock pins help prevent accidental separation of hose couplings during blasting.
- **3.2.4** Make sure that all compressed-air supply hose connections are secured with safety lock pins and safety cables to prevent accidental separation or disconnection. Safety cables are listed in Section 8.1 of this manual.

A WARNING

Hose disconnection while under pressure could cause serious injury or death. Use safety lock pins and safety cables on all coupling connections to help prevent hose couplings from accidental disconnection.

- **3.2.5** Connect the control cord to the control panel lead cord marked "OPERATOR".
- **3.2.6** Connect an air line between a source of respirable breathing air meeting the requirements for Grade D or higher quality, and the CPF filter inlet. See Section 2.4. The maximum inlet pressure for the CPF Filter must not exceed 150 psi.

A DANGER

Do not connect the CPF Filter, or any other regulator or filter, to bottled air or any other air source that does not have a pressure reducing valve that reduces pressure to a maximum of 150 psi. Failure to comply with this warning will cause low pressure devices to explode under the high pressure of bottled air. Such an explosion could cause severe injury or death.

A WARNING

If twist-on type air hose couplings are used, they must be secured by safety pins or wires to prevent accidental disconnection. Hose disconnection while under pressure could cause serious injury or death.

- **3.2.7** Make sure that all blast hose and compressedair hose connections are secure, and that coupling lock pins are in place.
- **3.2.8** Make sure the choke valve is open, (handle inline with the valve and piping).
- **3.2.9** Close the Quantum abrasive metering valve. Closed position is when the knob is turned fully clockwise. See Section 4.1.

CONTRACTOR SERIES BLAST MACHINE, 4 & 6 CU. FT. WITH MILLENNIUM ELECTRIC, PRESSURE RELEASE REMOTE CONTROLS

Compressed Air and Abrasive Consumption Consumption rates are based on abrasive that weigh 100 pounds per cubic foot									
	Pressure At The Nozzle (psi) Air, Power								
Orifice									and Abrasive
Size (in.)	50	60	70	80	90	100	125	140	Requirements
	11	13	15	17	19	20	25	28	Air (cfm)
No. 2	67	77	88	101	112	123	152	169	Abrasive (lbs/hr)
1/8"	2.5	3	3.5	4	4.5	5	5.5	6.5	Compressor (hp)
	26	30	33	38	41	45	55	61	Air (cfm)
No. 3	150	171	196	216	238	264	319	353	Abrasive (lbs/hr)
3/16"	6	7	8	9	10	10	12	14	Compressor (hp)
	47	54	61	68	74	81	98	108	Air (cfm)
No. 4	268	312	354	408	448	494	608	676	Abrasive (lbs/hr)
1/4"	11	12	14	16	17	18	22	24	Compressor (hp)
	77	89	101	113	126	137	168	186	Air (cfm)
No. 5	468	534	604	672	740	812	982	1085	Abrasive (lbs/hr)
5/16"	18	20	23	26	28	31	37	42	Compressor (hp)
	108	126	143	161	173	196	237	263	Air (cfm)
No. 6	668	764	864	960	1052	1152	1393	1538	Abrasive (lbs/hr)
3/8"	24	28	32	36	39	44	52	59	Compressor (hp)
	147	170	194	217	240	254	314	347	Air (cfm)
No. 7	896	1032	1176	1312	1448	1584	1931	2138	Abrasive (lbs/hr)
7/16"	33	38	44	49	54	57	69	77	Compressor (hp)
	195	224	252	280	309	338	409	452	Air (cfm)
No. 8	1160	1336	1512	1680	1856	2024	2459	2718	Abrasive (lbs/hr)
1/2"	44	50	56	63	69	75	90	101	Compressor (hp)

- For nozzle sizes 3/8" to 1/2", blast machines should be equipped with 1-1/4" or larger piping and inlet valve to prevent pressure loss.
- Air requirements were measured by a flow meter under actual blasting conditions, and are therefore lower than figures for air alone, with no abrasive.
- Horsepower requirements are based on 4.5 cfm per horsepower.
- Figures are for reference only, and may vary for different working conditions. Several variables, including metering valve adjustments, can affect abrasive flow.
- Figures show approximate compressed air and abrasive consumption when nozzles are new. Consumption will increase as the nozzle wears.


Figure 4

3.2.10 Open the safety petcock on the inlet section of the Millennium valve. The petcock is open when the lever is in-line with the petcock, as shown in Figure 5.

A WARNING

To prevent severe injury or death from accidental activation of the blast machine, open the safety petcock when the blast machine is not in use. Opening the petcock prevents unintentional blasting. The control handle can not activate the machine when the petcock is open.

3.2.11 Make sure that the control handle lever is in the up (no blast) position, and that the handle lever and safety lock move freely.



CONTRACTOR SERIES BLAST MACHINE, 4 & 6 CU. FT. WITH MILLENNIUM ELECTRIC, PRESSURE RELEASE REMOTE CONTROLS

3.2.12 Check to make sure that the handle lever will not engage the switch unless the safety lever lock is pulled down.

A WARNING

Malfunctioning control handles could cause unintentional actuation of a blast machine, or prevent a machine from deactivating upon release. Malfunctioning control handles must be taken out of service immediately and repaired or replaced. Serious injury or death can result from unintentional blasting.

3.2.13 Plug the power cord into an appropriate power source (120-volt AC or 12-volt DC). Do not use 120 volt AC models in any application where water exposure is possible, unless the power source is protected by a ground-fault circuit interrupt. 12-volt units are furnished with a pigtail with ring terminals to connect to a battery.

A WARNING

Do not use electrical adaptors that eliminate the ground prong on 120 volt plugs. Doing so can cause electric shock, and damage equipment.

- **3.2.14** Make sure all hoses and electrical connections are secure.
- **3.2.15** Close the air valve on the compressor. Start the compressor, and bring it to operating temperature and pressure. The pressure must be more than 30 psi, but not exceed 150 psi.
- **3.2.16** Slowly open the compressor air valve, to pressurize the air supply line. Listen for any open lines or leaks.
- **3.2.17** Pressurize the breathing air supply line, and adjust pressure on the CPF Filter outlet, to the pressure stated in the respirator manual.
- **3.2.18** Load abrasive into the machine by following the instructions in Section 3.5.
- **3.2.19** Do not allow anyone within 10 feet of the blast machine except machine tenders, who are appropriately fitted with approved protective equipment. The blast operator could pressurize and depressurize the machine without warning.

WARNING

All persons except for the machine tender must stay clear of the blast machine. The blast operator may pressurize or depressurize the machine at any time. The noise generated by the sudden release of compressed air when the machine is pressurized or depressurized, may startle bystanders, and may vent abrasive under pressure. Either condition could result in injury. The machine tender must wear a suitable, approved respirator, plus approved eye, face, and hearing protection.

3.2.20 When the blast operator is ready to blast, either the operator or the machine tender, while standing back and facing away from the concave filling head of the blast machine and the exhaust muffler, closes the safety petcock. Closing the petcock prepares the machine for remote operation and activation by the control handle

3.3 Blasting

WARNING

Before blasting, test the coating and substrate for toxic materials (such as lead or other heavy metals, or asbestos). These hazards require special measures to protect the operators and the environment.

No dust is safe to breathe. Abrasive blasting produces harmful dust. Failure to wear approved respirators could result in serious lung disease or death. Blast operators must wear properly fitted and maintained NIOSH-approved, type-CE supplied-air respirators approved for abrasive blasting.

During abrasive blasting, abrasive particles and dust in the area around the blast machine and blast nozzle become airborne. Everyone working in the vicinity of abrasive blasting must wear properly maintained, NIOSH-approved, respiratory protection appropriate for the job site hazards.

Loud noise generated by the use of compressed air could cause hearing damage. Everyone in the blasting area must wear approved eye and hearing protection.

- **3.3.1** Operators must wear appropriate protective gear, including: abrasive-resistant clothing, leather gloves, eye and hearing protection, and a NIOSH-approved Type CE Supplied-Air Respirator.
- **3.3.2** Hold the blast hose securely and point the nozzle only at objects intended to be blast cleaned.
- **3.3.3** Pull back the safety lever lock and depress the remote control handle. Within a few seconds, the pop-up valve automatically closes, and the blast machine will pressurize to start blasting.

A CAUTION

Be prepared for the recoil from the blast hose. Blasting should begin within a few seconds after pressing the control handle lever.

A WARNING

OSHA requires the use of remote controls on all blast machines. To comply with OSHA regulations, the remote control handle, which starts and stops the flow of air and abrasive, must be held down manually. Do not tie down the control handle lever or attempt to bypass any part of the remote control system. Doing so will defeat the purpose of the fail-to-safe feature of the remote control. Serious injury or death could result from uncontrolled blasting. Ref. 29 CFR 1910.244 (b).

- **3.3.4** If the metering valve is closed, as instructed, only air will exit the nozzle.
- **3.3.5** Adjust abrasive flow per Section 4.1.

3.4 Stop Blasting

- **3.4.1** To stop blasting; release the control handle lever. The pop-up valve automatically drops when air is expelled from the machine and pressure equalizes.
- **3.4.2** When the control handle lever is released, the control handle safety lever will flip up to lock the handle lever in the up (no blast) position.
- **3.4.3** Make sure the control handle safety lever lock is up, and that it prevents the handle lever from engaging.
- **3.4.4** Always open the safety petcock during work breaks and before filling the blast machine. Opening the petcock prevent unintentional blasting.

3.5 Loading Abrasive into the Blast Machine

A WARNING

Obtain a material safety data sheet (MSDS) for the blast abrasive. Abrasive blasting with sands containing crystalline (free) silica can lead to serious or fatal respiratory disease. As NIOSH recommends, do not use abrasives containing more than trace amounts (more than one percent) free silica.

When approaching an idle blast machine, and before loading the blast machine with abrasive, always check to make sure the safety petcock is open. If it is closed, open it while standing back and facing away from the concave head and exhaust muffler. This step is especially important if one worker (a machine tender) loads the machine with abrasive while another worker (the blast operator) controls the blasting. The blast operator could pressurize the machine before the machine tender has moved away from the machine. During pressurization, abrasive could be forced out of the top of the machine, and cause injury.

3.5.1 Load abrasive into the machine by pouring it through the screen into the concave head. Use a screen placed over the head to prevent objects from falling inside. Foreign objects will jam the machine. Abrasive flows through the filling port into the machine. Keep the abrasive level below the pop-up valve. Abrasive resting on the pop-up valve could be forced up and out of the top of the machine when the machine is pressurized.

NOTE: Use only abrasives specifically manufactured for blast cleaning, that are compatible with the surface being blasted. Abrasive produced for other applications may be inconsistent in size and shape, and contain particles that could jam the abrasive metering valve, or cause irregular wear. Some abrasive may contain salts, corrosives, or other materials that could contaminate the surface being blasted.

3.5.2 When the blast operator is ready, either the operator or the machine tender while standing back and facing away from the exhaust muffler, closes the safety petcock.

3.6 Emptying the Machine of Abrasive

- **3.6.1** When working in environments subject to extreme temperature changes, or very humid conditions, condensation may develop inside the machine. Condensation dampens abrasive and causes flow problems. To prevent this, empty the machine of all abrasive when shutting down for the day. This will eliminate trouble from moist abrasive when starting a new day's blasting. One way to avoid having to empty the machine is to load only as much abrasive as will be used during the work period. If the machine must be purged of abrasive, do the following.
- **3.6.2** With the blast machine off, turn the blast pressure down to approximately 40-50 psi, close the choke valve and set the abrasive metering valve at full open.
- **3.6.3** To prevent rapid wear of the nozzle holder threads, the nozzle should be firmly attached to the nozzle holder. Removal of the nozzle is not recommended. If circumstances require the nozzle to be removed, also remove the nozzle washer. Purging the machine without a nozzle in place will erode the thread area of the nozzle holder, which could cause a hazardous condition.
- **3.6.4** Point the nozzle (or hose end) into a drum or suitable container, or in the direction the abrasive is to be disposed.
- **3.6.5** Hold the hose securely (do not leave the hose unattended), and pressurize the machine by activating the control handle. Be prepared for surging or recoil of the hose, which can be severe.
- **3.6.6** When the machine is empty, release the control handle lever, open the safety petcock, and open the choke valve.

A WARNING

The threads on the nozzle and nozzle holder must be inspected each time the nozzle is secured to the holder. Make sure the threads are not worn, and that the nozzle holder securely grips the nozzle. The nozzle washer must also be inspected for wear. Worn nozzle washers cause thread erosion. A loose fitting nozzle may eject from the holder under pressure and could cause severe injury.

3.6.7 If the nozzle was removed, thoroughly inspect the nozzle holder threads for wear before installing the nozzle washer and attaching the nozzle.


3.7 Shutdown

- **3.7.1** When finished blasting, and after cleanup is completed, remove the respirator outside the respiratoruse area and where the air is safe to breathe.
- **3.7.2** Turn off electrical power to the control panel.
- **3.7.3** Close the compressed-air supply valve at the compressor.
- **3.7.4** Drain receiver tank, air filters, and water collecting devices, and bleed the compressed-air supply hose.
- **3.7.5** Shutdown the compressor.
- **3.7.6** Cover the blast machine when not in use.

4.0 ADJUSTMENTS

4.1 Quantum Abrasive Metering Valve, Figure 6


- **4.1.1** Abrasive flow is adjusted at the metering valve located at the bottom of the blast machine.
- **4.1.2** The hole in the knob enables the operator to monitor its rotation and count turns as the knob is turned. This helps return the setting to its original position, should temporary adjustments be required.
- **4.1.3** The hole in the knob enables the operator to monitor its rotation and count turns as the knob is turned. This helps return the setting to its original position, should temporary adjustments be required.



- **4.1.4** The valve is closed when the knob is fully clockwise. Begin with the knob set 1-1/2 turns from fully closed. While the operator is blasting, the machine tender turns the knob no more than 1/4 turn counterclockwise, to increase abrasive flow. Allow 10 to 15 seconds for the flow to stabilize before readjusting. Continue making adjustments as described until the correct flow is attained.
- **4.1.5** Optimum abrasive flow depends on the type and size of abrasive and blasting pressure, and can best be determined by experience. Use as little abrasive as possible while maintaining the maximum cleaning rate. The air/abrasive mixture should be mainly air. As a rule, the stream of abrasive coming out of the nozzle should barely discolor the air when seen against a contrasting background.

4.2 RLX Switch Contact, Figure 7

4.2.1 The handle lever should engage the switch when it is approximately 1/8" to 3/16" from full down position. If the handle lever is too far up when it engages, it will cause excessive pressure on the switch and damage it.



- **4.2.2** Use a screw driver or similar object to pry the metal switch bracket up or down as required so the boss on the handle lever makes contact with the switch within 1/8" to 3/16" window.
- **4.2.3** Check the adjustment by listening for the switch to click as the handle lever is lowered. It should engage within the specified window. If resistance is felt after the switch is engaged, and before the handle lever bottoms, the switch is too high and should be lowered to prevent damage to the switch.

5.0 PREVENTIVE MAINTENANCE

5.1 Daily Inspection

- **5.1.1** With the air off, before blasting, do the following:
- Empty the abrasive trap and clean the abrasive trap screen. Do this at least twice a day, or more often if the machine is frequently cycled. Failure to clean the abrasive trap on a regular basis is a major cause of system malfunction. See Section 6.10.
- Inspect the blast hose for wear; look for soft spots.
 Soft spots mean the hose is worn. Replace the blast hose before the tube wears as far as the fabric plies.

A WARNING

Worn blast hose could suddenly fail by bursting. Couplings and nozzle holders may not adequately grip worn hose causing them to blow-off under pressure. Compressed air and abrasive escaping from a burst hose, or disconnected coupling or nozzle holder, could cause severe injury.

- Check to make sure that couplings are secure and lock pins and safety cables are in place.
- Make sure the nozzle washer is in place and not worn.

WARNING

The threads on the nozzle and nozzle holder must be inspected each time the nozzle is secured to the holder. Make sure the threads are not worn, and that the nozzle holder securely grips the nozzle. The nozzle washer must also be inspected for wear. Worn nozzle washers cause thread erosion. A loose fitting nozzle may eject from the holder under pressure and could cause severe injury.

- Inspect the RLX Control Handle, look for the following:
 - The lever must not engage the switch unless the safety lever lock is pulled down. See Section 4.2.
 - The handle lever must return to the "up" position when released.

- The safety lever lock must return to the "up" position when the handle lever is released.
- Both the handle lever and safety lever lock must move freely with no drag or binding.

A WARNING

Malfunctioning control handles could cause unintentional actuation of a blast machine, or prevent a machine from deactivating upon release. Malfunctioning control handles must be taken out of service immediately and repaired or replaced. Serious injury or death can result from unintentional blasting.

5.1.2 During blasting, inspect the following:

- Inspect all couplings and coupling gaskets for leaks.
- Check the blast machine for leaks. If leaks are found around the pop-up valve, inspection door, or pipe fittings at the bottom of the cone, stop blasting immediately and repair or replace worn parts. If leaks are allowed to continue, abrasive erosion could cause irreparable damage to the blast machine.
- Check all external piping, control hoses, and valves for leaks. If leaks are found, stop blasting and repair.
- Inspect blast hose, couplings, and nozzle holders for leaks. At the first sign of a leak, stop blasting and inspect all items for wear.

WARNING

Leaks around couplings and nozzle holders indicate worn or loose-fitting parts. Nozzle holders and couplings that do not fit tight on hose, and nozzles that do not fit tight in nozzle holders could disconnect while under pressure. Impact from nozzles, couplings, hoses, or abrasive, from parts disconnected by pressure during operation could cause severe injury.

5.2 Weekly Inspection

5.2.1 With the air off, before blasting, do the following:

- Remove the nozzle for inspection. Replace if the orifice diameter is worn 1/16" or more, or if the liner is cracked.
- If the optional air filter is used, inspect the filter element, and clean the bowl.

5.2.2 During blasting do the following:

 Note the time it takes to fully depressurize the machine after the control handle is released. When depressurizing time increases noticeably, inspect the exhaust muffler per Section 6.5.

5.3 Monthly Inspection

5.3.1 With the air off, before blasting, do the following:

- Check the pop-up valve's urethane coating for cracks and grooves. Replace the pop-up valve at the first sign of wear. See Section 6.8.
- Inspect the rubber pop-up seal, and replace at the first sign of wear, drying, or cracking. See Section 6.9
- Inspect exhaust muffler for blockage and wear, per Section 6.5.

5.4 Periodic Inspection

- **5.4.1** Millennium Control Valves: For safety and to avoid unscheduled downtime, periodically inspect the internal parts of the inlet and outlet valves, and abrasive trap. Inspect for wear and lubrication on O-rings, pistons, springs, seals, and castings. See Service Maintenance in Sections 6.3, 6.4, 6.5, and 6.10.
- **5.4.2** Quantum metering: To avoid unscheduled downtime, periodically inspect the internal parts of the Quantum metering valve for wear. See Service Maintenance in Sections 6.7.
- **5.4.3** RLX Electric Control Handle: Periodically clean around the springs, handle lever, and lever lock to ensure that the unit is free of abrasive and debris that may cause the handle lever or lever lock to bind. See Section 6.6.

6.0 SERVICE MAINTENANCE

A WARNING

Failure to observe the following before performing any maintenance could cause serious injury or death from the sudden release of compressed air.

- Depressurize the blast machine.
- Lock-out (Be certain the air supply is off and that it cannot be started while work is in process) and tag-out (Be certain the air supply is clearly marked to prevent restarting while work is in process) the compressed air supply
- Bleed the air supply line to the blast machine.
- 6.1 Removing Damp Abrasive From The Blast Machine.
- **6.1.1** To clear a minor blockage caused from damp abrasive, during operation, rapidly open and close the choke valve several times.
- **6.1.2** For more difficult blockages, proceed as follows: See Section 6.2 to check for obstructions in the metering valve.
- **6.1.2.1** With the blast machine off, disconnect the blast hose and remove the gasket from the quick coupling on the machine.
- **6.1.2.2** Place the machine so that the outlet is pointed away from any objects or persons.

WARNING

The machine's outlet must be pointed away from any objects or persons. Stand clear of the path of exiting abrasive. It may come out at high velocity. Impact from exiting abrasive could cause severe injury.

- **6.1.2.3** Close the choke valve and fully open the abrasive metering valve. Pressurize the machine to force out any damp abrasive.
- **6.1.2.4** When the obstruction has been removed, depressurize the machine. Remove the nozzle and nozzle washer, and reconnect the hose. Open the choke

valve and close the abrasive metering valve. Pressurize the machine to clear the hose. When the hose is cleared, depressurize the machine and attach the nozzle washer and nozzle.

WARNING

The threads on the nozzle and nozzle holder must be inspected each time the nozzle is secured to the holder. Make sure the threads are not worn, and that the nozzle holder securely holds the nozzle. The nozzle washer must also be inspected for wear. Worn nozzle washers could erode nozzle threads. A loose fitting nozzle may eject under pressure and could cause severe injury.

- **6.1.2.5** With the hose cleared, start the machine using normal procedures.
- 6.2 Clearing Obstructions In The Abrasive Metering Valve And Blast machine.
- **6.2.1** If the nature of the obstruction permits emptying the machine of abrasive, do so by following the instructions per Section 3.6.
- **6.2.2** Turn off the compressed air supply. Lock-out and tag-out the air supply, and bleed the air supply line to the blast machine.
- **6.2.3** Remove the wing nuts securing the abrasive metering valve's inspection plate.
- **6.2.4** Check the metering valve for blockage, by inserting fingers into the opening to feel for an obstruction or foreign object.
- **6.2.5** If the metering valve is clear, remove the blast machine inspection door, and check for foreign objects.
- **6.2.6** Make sure the inspection door gasket is in good condition and in place before bolting the door onto the machine.
- **6.2.7** Make sure the abrasive metering valve inspection plate O-ring is in good condition and in place before reassembling the inspection plate.
- **6.2.8** Check to make sure all inspection doors are secure before starting the air supply.


6.3 Millennium Valve Inlet Segment, Ref. Figure 8.

NOTE: Two service kits are available for the Millennium valve inlet segment. To avoid unscheduled down time, both kits should be kept on-hand. Replace all the seals provided in the seal service kit whenever the valve is opened. Use the plunger tip kit when replacing the plunger tip.

- **6.3.1** Unscrew the six socket head screws to remove the cylinder cap, cylinder cap gasket, and spring.
- **6.3.2** Remove the cylinder sleeve by screwing two 1/4-NC screws into the holes in the end of the sleeve and by pulling the screws to remove the sleeve from the body. If the sleeve is too tight to remove by hand, use a puller. Remove the screws after the sleeve is removed.
- **6.3.3** To remove the piston, screw a 1/4-NC screw into the center of the socket head screw, grip the screw, and pull out. If the piston is too tight to remove by hand, use a puller. Remove the screw after the piston is removed.
- **6.3.4** It is not necessary to separate the plunger from the piston unless the metal of either part is scored. To remove the plunger, insert a rod through the hole in the

lower part of the plunger. Hold the rod to prevent the plunger from turning, while using a 5/16" hex key to remove the socket screw from inside the piston.

- **6.3.5** If the plunger tip is worn, use a 3/16" hex key to remove the button screw, washer and tip.
- **6.3.6** Clean all items and inspect for wear. Replace all seals and O-rings (they are included in the service kit) and replace all worn or damaged parts.
- Inspect the plunger tip. Replace the tip if worn or damaged.
- Inspect the machined plunger seat in the valve body for wear. The body must be replaced if the seat is worn.
- **6.3.7** If the plunger and piston were separated as noted in paragraph 6.3.4, apply removable thread sealant to the socket head screw, and reassemble the parts using a new O-ring supplied with the service kit.
- **6.3.8** Lubricate the O-rings and all U-seals with a silicon-based lubricant.
- **6.3.9** Replace both O-rings in the valve body.




- **6.3.10** Place the U-seals into the grooves on the piston, the open side of the large seal faces the plunger, and the open side of the small one faces away from the plunger, as shown in Figure 8.
- **6.3.11** Install the plunger and piston assembly into the body. Use care, making sure the open side of the large (lower) U-seal does not fold back during assembly. Tucking the lip of the seal in, while applying pressure to the piston eases assembly.
- **6.3.12** Place the O-ring on the cylinder sleeve, and insert the sleeve (O-ring end faces up) into the body, making sure the open side of the small (upper), piston U-seal does not fold back during assembly.
- **6.3.13** Install the spring, cylinder cap gasket, and cylinder cap.
- **6.3.14** Tighten the six socket head screws in sequence to secure the cap.
- **6.3.15** If fittings on the body were removed, make sure the 1/16" orifice fitting is threaded into the port, as shown in Figure 8.

6.4 Millennium Valve Outlet Segment, Ref. Figure 9

NOTE: Two service kits are available for the Millennium valve outlet segment. To avoid unscheduled down time, both kits should be kept on-hand. Replace all the seals provided in the service kit whenever the valve is opened, or when replacing the diaphragm. Use the muffler service kit when replacing the muffler.

- **6.4.1** Loosen the exhaust piping union nut.
- **6.4.2** Unscrew the four hex head cap screws securing the outlet body to the inlet, and remove the exhaust assembly.
- **6.4.3** Screw a 1/4-NC screw into the threaded hole in the bottom of the piston. Grip the screw, and pull out to remove the piston. Remove the screw after the piston is extracted.
- **6.4.4** Screw 1/4-NC screws into the threaded holes in the bottom of the inner sleeve. Grip the screws, and pull out to remove the sleeve. Remove the screws after the sleeve is extracted.
- **6.4.5** Remove the diaphragm from the bottom of the exhaust valve body.

- **6.4.6** Clean all items and inspect for wear. Replace the diaphragm, seals and O-rings (they are included in the service kit) and replace all worn or damaged parts.
- Place the piston into the inner sleeve and check movement. If the parts drag, or if abraded or worn they must be replaced.
- Inspect the machined seat in the exhaust body for wear. The body must be replaced if the seat is worn.
- **6.4.7** Inspect the exhaust muffler per Section 6.5.
- **6.4.8** Lubricate the U-seal with a silicon-based lubricant, and place the U-seal into the groove in the piston. The open side of the seal must face the bottom of the piston, as shown in Figure 9.



- **6.4.9** Verify that the inner sleeve O-ring is in the lower groove, not in the upper groove which has the vent hole.
- **6.4.10** Insert the piston into the sleeve.
- **6.4.11** Place the diaphragm in the valve body.

- **6.4.12** Slide the piston and sleeve assembly into the valve body, the piston faces away from the bottom of the body, as shown in Figure 9.
- **6.4.13** Place the flange O-ring into the flange groove, and position the outlet assembly onto the inlet section. Align the exhaust piping by hand tightening the four cap screws with lockwashers, and union nut.
- **6.4.14** Tighten the four hex head cap screws. After the screws are secure, tighten the exhaust piping union.

6.5 Exhaust Muffler, Figure 9

- **6.5.1** Separate the two halves of the muffler housing by removing the six screws, and pry the halves apart. Note that the screw holes in the housing are not the same size. The side of the housing with the hex recess has a smaller diameter than the other. The screw is inserted into the larger diameter hole, and grips the smaller diameter hole.
- **6.5.2** Remove the muffler element, rubber liner and screen from each housing half.
- **6.5.3** Inspect the inside of the muffler element for a build-up of deposits that blocks the porosity of the element. Replace the elements if plugged.
- **6.5.4** Inspect the two sealing O-rings on the exhaust body, and replace them if worn or damaged.
- **6.5.5** Clean and inspect all parts that are to be reused, replace if worn. Reassemble the exhaust muffler in reverse order.

6.6 RLX Electric Control Handle


6.6.1 Spring replacement

6.6.1.1 To replace the lever lock spring, follow the instructions in Section 6.6.2. To replace the handle lever spring, follow the instructions in Section 6.6.3.

6.6.2 Lever lock replacement, Figure 10


6.6.2.1 Remove the lock nut from the shoulder screw. Before removing the screw, note the positions of the spacers and spring, as shown in Figure 10. The bent end of the spring is toward the inside and forcing the lever lock up. The straight end is toward the outside facing down and against the tab.

- **6.6.2.2** Install a new lever lock and spring, and reassemble in reverse order.
- **6.6.2.3** Make sure the lever lock moves freely, raises to full up position, and that the handle lever will not engage unless the lever lock is pulled down.



6.6.3 Handle lever replacement, Figure 11

6.6.3.1 Remove the lock nut from the shoulder screw. Before removing the screw, note the positions of the spacers and spring, as shown in Figure 11. The bent end of the spring is against the handle lever and facing up. The straight end is against the body and facing down.




6.6.3.2 Install a new handle lever and spring, and reassemble in reverse order.

6.6.3.3 Make sure the handle lever moves freely, raises to full up position, and will not engage unless the lever lock is pulled down.

6.6.4 Switch replacement

- **6.6.4.1** Remove the handle lever per Section 6.6.3.
- **6.6.4.2** Remove screws holding the switch and cord clamps.
- **6.6.4.3** Remove the compression nut, thrust washer and gasket from the connector shell per Figure 12.




- **6.6.4.4** Remove the shell from the coupling insert assembly.
- **6.6.4.5** Loosen the cable clamp and set screws holding the cord, and remove the cord from the assembly.
- **6.6.4.6** Install a new switch and cord assembly using Terminals No. 1 and 3.
- 6.6.4.7 Adjust switch per Section 4.2.
- **6.6.4.8** Reassemble in reverse order. Make sure the springs are in place, the handle lever and lever lock move freely, and the handle lever will not engage unless the lever lock is down.
- **6.6.4.9** Reassemble the handle lever, making sure the spacer washers and spring are in place.
- **6.6.4.10** Make sure the handle lever moves freely, raises to full up position, and will not engage unless the lever lock is pulled down.

6.7 Quantum Manual Metering Valve, Figure 13

NOTE: A service kit is available for the Quantum metering valve. To avoid unscheduled down-time, a kit should be kept on-hand. Replace all the seals provided in the kit whenever the valve is opened.

6.7.1 Empty the machine of abrasive. Turn off the compressed air supply. Lock-out and tag-out the air supply, and bleed the air supply line to the blast machine.




- **6.7.2** If the valve requires immediate service, and the machine cannot be emptied of abrasive, turn the adjusting knob fully clockwise to shut-off abrasive flow. If the valve is worn so that abrasive does not shut-off, remove the inspection plate, and insert a rag or similar object into the opening to block the flow of abrasive.
- **6.7.3** Loosen the wing nuts to remove the inspection plate.
- **6.7.4** Remove the four socket head screws securing the metering housing, and remove the metering assembly.
- **6.7.5** The upper and lower bodies do not need to be removed from the blast machine to service the metering assembly. Inspect the bodies for wear, and replace if worn.
- **6.7.6** Turn the metering shaft clockwise to remove the shaft from the metering screw.

- **6.7.7** Loosen the knob nut, and remove the knob assembly from the housing.
- **6.7.8** Use a drive pin and hammer to drive the roll pin from the knob, and remove the knob.
- **6.7.9** Remove the metering screw by pushing it out the front of the knob nut.
- **6.7.10** Inspect the metering screw for damage and any signs of abrasive ingress or metal filings.
- **6.7.11** Clean the metering screw threads, and test the conditions of the threads with the metering plate shaft. Replace the metering screw if there is any resistance, binding or metal filings.
- **6.7.12** Remove the O-ring from the knob nut, and remove the O-ring and wiper from the housing.
- **6.7.13** Thoroughly clean and inspect all parts that are to be reused.
- **6.7.14** Place a new O-ring in the knob nut.
- **6.7.15** Place a new O-ring and wiper seal in the housing. A generous amount of silicon-based lubricant helps placement of the parts. The small side of the wiper seal faces away from the O-ring.
- **6.7.16** Insert the metering plate shaft through the housing bore, and wipe off any lubricant on the metering plate side of the bore.
- **6.7.17** Reassemble the metering screw, nut, knob, and drive pin. Applying a small amount of silicon-based lubricant on the straight end of the metering shaft eases insertion through the nut O-ring.
- **6.7.18** Apply a molybdenum disulfide or graphite based anti-seize lubricant to the metering shaft and metering screw threads, and thread the shaft onto the screw.
- **6.7.19** Before installing the housing assembly, if the upper and lower bodies have not been inspected, do so now, and replace if worn.
- **6.7.20** Place a new O-ring in the groove on the face of the upper body.
- **6.7.21** Insert the metering plate (flat side up) through the upper body opening. Take care not to displace the O-ring.
- **6.7.22** Install the four socket head screws to secure the metering housing. Hand-tighten all screws before tightening with a wrench.

- **6.7.23** Place a new O-ring on the inspection plate, and securely attach the plate.
- **6.7.24** Service of the metering assembly is complete. Test the machine and piping for air leaks before use.


6.8 Replacing The Pop-Up Valve, Figure 14

- **6.8.1** All service on the pop-up valve must be done with the compressed air off and the air supply locked-out and tagged-out.
- **6.8.2** To gain access to the pop-up valve, remove the inspection door assembly.
- **6.8.3** Using a small pipe wrench, unscrew the pop-up valve guide by turning it counterclockwise. Remove the pop-up valve and guide from the machine.
- **6.8.4** While the pop-up valve is out, check alignment as follows: Screw a 1-1/4" nipple, which is at least 12" long, into the elbow in place of the pop-up guide. Check the alignment through the pop-up filling port. The nipple should be close to the center of the port. If it is not, adjust the horizontal pipe. A misaligned pop-up valve could result in early valve failure, or abrasive leakage when the machine is pressurized or depressurized.



6.8.5 Slide the new pop-up valve over the guide, and then screw the valve guide (with the pop-up valve on it) into position inside the machine. Tighten the guide snug, but not wrench-tight. Over-tightening the guide will make it difficult to remove the next time the pop-up valve needs replacement.

- **6.8.6** Refer to Figure 15 to check the pop-up height. If the pop-up sits too low, misalignment could occur when the pop-up comes up against the seal. If the pop-up sits too high, it will take longer for abrasive to flow through the opening. Adjust the height by replacing the guide with one that is longer or shorter.
- **6.8.7** Put a new gasket on the inspection door assembly before bolting the door onto the machine.



6.9 Replacing The Pop-Up Seal

- **6.9.1** All service on the blast machine must be done with the compressed air off and the air supply locked-out and tagged-out.
- **6.9.2** Remove the old seal using fingers, screwdriver, or similar object, to work the seal out of the retaining groove.
- **6.9.3** Push the new seal all the way through the port and then fit it into the retaining groove. For the last few inches, pull up on the seal and allow it to pop into position.

6.10 Abrasive Trap

NOTE: A service kit is available for the abrasive trap. To avoid unscheduled down-time, a kit should be kept on-hand.

- **6.10.1** All service on the abrasive trap must be done with the compressed air off and the air supply locked-out and tagged-out.
- **6.10.2** Clean the abrasive trap screen and trap at least twice a day. NOTE: Failure to clean the abrasive trap on a regular basis is a major cause of system malfunction.
- **6.10.3** To check the abrasive trap screen, loosen the top thumbscrew, and swing the lock bar off the cap, and remove the cap.
- **6.10.4** Remove the screen and inspect it for wear and blockage. Replace it when it is clogged or worn. Keep spare screens on hand. Do not install the screen in the trap until the bottom section of the trap is cleaned per the following instructions.
- **6.10.5** To clean the bottom section of the trap, loosen the bottom thumbscrew, and swing the lock bar off the bottom cap, and remove the cap.
- **6.10.6** Empty all abrasive from the bottom and top sections.
- **6.10.7** Install the screen in the top section. The small end of the screen must face up.
- **6.10.8** Reassemble the top and bottom caps. Make sure the O-rings are in place on the caps before assembly, and the screen gasket is in place in the top cap.

7.0 TROUBLESHOOTING

NOTE: This section only <u>identifies</u> conditions and problems in the blast machine and remote control system. Always refer to the appropriate section of this manual, or manuals for accessory equipment, <u>before servicing</u> the equipment.

WARNING

To avoid serious injury, observe the following when troubleshooting the machine and remote controls.

- Turn off the compressed air, and lock-out and tag-out the air supply.
- When checking the controls requires air, always enlist the aid of another person to operate the control handle while holding the nozzle securely and pointing it in a safe direction.
- Never strap the remote control handle lever down in the operating position.

Shorting electrical components could result in serious electrical shocks, or damage equipment. All electrical troubleshooting must be performed by a qualified electrician.

- 7.1 Neither abrasive nor air comes out of the nozzle when the RLX Control Handle is pressed
- **7.1.1** Make sure the machine is pressurized. See Section 7.3.
- **7.1.2** Depressurize the blast machine. After the popup valve has dropped, remove the nozzle, and check it for obstruction.
- **7.1.3** Make sure both the abrasive metering valve and choke valve are open.

7.2 Air only (no abrasive) comes out the nozzle

- **7.2.1** Quantum abrasive metering valve may be closed or needs adjustment. See Section 4.1.
- **7.2.2** Blast machine may be empty.
- **7.2.3** Abrasive may be damp. See Section 6.1 to clear damp abrasive.
- **7.2.4** Check the media metering valve for obstructions. See Section 6.2.

7.3 Blast machine will not pressurize

- **7.3.1** Listen to the control panel to determine if the solenoid clicks when the control handle is pressed and released.
- If it does click, the fault may not be electrical. Proceed from section 7.3.4 for pneumatic checks.
- If it does not click, do electrical checks per Section 7.3.2. Confirm this by pushing the white manual override button on the solenoid valve. This should operate the valve if the fault is electrical.
- **7.3.2** Check for fault in the control panel by removing the control cord from the 5' lead cord coming from the panel. Jumping across terminals No. 1 and 3 on the lead cord lo-profile connector should cause the solenoid to click. If the solenoid does not click, check the following:
- Check for faulty fuse or loose connections in the control panel.
- Check for inadequate power to the control panel.
- Check continuity of all panel wiring and solenoid.
- Check for faulty transformer (120 volt systems only).
- **7.3.3** If the solenoid does click, check continuity of the control cord (terminals no. 1 and 3), and each control cord extension. Another method is to listen to the solenoid and short across socket No. 1 and 3 on the extension cord. If it clicks, check the RLX switch by disconnecting the control handle at the control cord. With the handle lever down, check continuity across pins No. 1 and 3 in the Lo-Profile connector. Repair or replace accordingly.
- **7.3.4** Make sure the safety petcocks are closed.
- **7.3.5** Check for air leaks in Millennium valve, connecting hose, and tube fittings in the panel.
- **7.3.6** Check the air filter on the control panel cover, 3/16" supply hose, and orifice fitting for blockage. Clean as necessary.
- **7.3.7** Open the safety petcock on the Millennium valve and press the control handle. If air does not come out the petcock, check for blockage in the control lines. If air does come out, the Millennium valve inlet section is not functioning. Turn off the compressed air supply and inspect internal parts for wear, and lubrication. See Section 6.3.
- **7.3.8** Make sure the compressor is on and all air supply valves to the machine are open.
- **7.3.9** Close the safety petcock, and press the control handle lever. Make sure no air escapes through the vent hole on the cylinder body of the inlet valve body. Air

escaping from this vent indicates worn seals in the inlet valve. See Section 6.3.

- **7.3.10** Insufficient-size air supply hose or reduced-size fittings between the compressor and blast machine. See Section 3.2.2.
- **7.3.11** Dirty filter in optional air filter. Check filter element.
- **7.3.12** Pop-up valve stuck, or internal piping worn or out of alignment. Inspect internal piping.

7.4 Blast machine will not depressurize or depressurizes too slowly

- **7.4.1** Abrasive trap screen blocked, or abrasive trap need cleaning. Clean the trap at least twice daily.
- **7.4.2** Exhaust muffler blocked. See Section 6.5.
- **7.4.3** Check for blockage in the control hose.
- **7.4.4** Remote control valves malfunctioning. Inspect the inlet and outlet valves per Section 6.3 and 6.4.

7.5 Outlet valve will not seal

7.5.1 Outlet valve diaphragm worn, or outlet valve requires service. See Section 6.4.

7.6 Heavy abrasive flow

- **7.6.1** Make sure the choke valve is open. The valve is open when the handle is in-line with the piping.
- **7.6.2** Abrasive metering valve may be open too far. See Section 4.1.
- **7.6.3** Check the abrasive metering valve for wear. Look for wear on the abrasive valve metering plate.

7.7 Abrasive surging

- **7.7.1** A certain amount of abrasive surge is normal at start-up. Should the flow of abrasive continue to surge, reduce the amount of abrasive in the air stream by adjusting the metering valve. See Section 4.1.
- **7.7.2** Make sure the choke valve is open. The valve is open when the handle is in-line with the piping.

7.7.3 Quantum abrasive metering valve may require service. See Section 6.7.

7.8 Intermittent abrasive flow

- **7.8.1** Moisture in the blast machine or in the air supply. Drain moisture from the compressor's receiver tank, and the blast machine's air filter. If moisture continues to be a problem, a dryer or after cooler may be required in the air supply line.
- **7.8.2** Abrasive may be worn from recycling. Replace abrasive.

7.9 RLX Control Handle lever fails to return to the non-blast position (up) when released

- **7.9.1** Check the handle lever for damage that may cause binding against the body.
- **7.9.2** Check the spring for damage or fatigue.
- **7.9.3** Replace the handle lever or spring as necessary.

7.10 RLX Control Handle lever lock fails to pop up when the handle is released

- **7.10.1** Check the lever lock for damage, or build up of debris or abrasive.
- **7.10.2** Check the lever lock return spring for damage or fatigue.
- **7.10.3** Replace lever lock or spring as necessary.

8.0 ACCESSORIES AND REPLACEMENT PARTS


8.1 Accessories

(-)	Cover, blast machine, for	
	4 cu. ft., 20" dia2035	8
	6 cu. ft., 24" dia0233	6
(-)	Screen, optional, for	
	4 cu. ft., 20" diameter2035	7
	6 cu. ft., 24" diameter0310	0
(-)	Safety Cable, 1-1/2" to 3" OD hose1501	3

8.2	Blast Machine, Figure 16	
Item	Description	Stock No.
1. 2. 3. 4. 5. 6.	Ball valve, 1-1/4" with handle	22532 23675 01857 01886
7. 8.	6 cu. ft. w/10" nipple	22845
9. 10. 11. 12. 13.*	Inspection door assembly, 6" x 8" Gasket, inspection door, 6" x 8" Seal, pop-up valve	02377 02369 02325
14. 15.* 16. 17. 18. 19. 20. 21.	1-1/2" manual drain Millennium valve	21336 08853 01818 01753 21517 02402 03825


22.	Abrasive trap 02011
23.	Wheel, secondary, 10" x 2.75 20349
24.	CPF-20 Air filter, optional 03578
25.	Cartridge, CPF filter03547
26.*	Coupling, nylon, for
	4 cu. ft., CQPS-121088
	6 cu. ft., CQPS-208413
27.*	Nozzle holder, nylon, for
	4 cu. ft., NHP-104106
	6 cu. ft., NHP-204127
28.*	Hose, Supa-T blast, for
	4 cu. ft., 1" ID x 50 ft
	6 cu. ft., 1-1/4" ID x 50 ft 23106
29.*	Nozzle, for
	4 cu. ft., TMP-523521
	6 cu. ft., TXP-623525
30.*	Washer, nozzle, for
	4 cu. ft., NW-25, pack of 10 91024
	6 cu. ft., NW-32, pack of 10 91026
31.*	Gasket, hose coupling, package of 10
	CQGP-2, for 4 cu. ft. (for Item 26) 08852
	CQGP-3, for 6 cu. ft. (for Item 26) 08853
32.	Adaptor, 1-1/4" NPT x JIC22529
33.**	Hose, 5-ft respirator extension, coupled 24510
34.**	Fitting, 1/4" NPT bulkhead 05605
35.**	Adaptor, 1/4" NPT x 3/8" hose 01019
*	Models shown are supplied with original blast
	machine systems.
**	Supplied with factory-installed CPF-20 Air Filter

option only.



8.3 Remote Control System Parts, Figure 17


Item	Description	Stock No.
1.	Millennium valve	21336
2.	Control panel, complete	
	12 volt	07677
	120 volt	07676
3.	RLX Electric Control handle	10840
4.	Hose, 4-ft. twinline cpld	21619
5	Cord, control w/ lo-profile connectors	
	50-ft. control	10835
	100 ft. control	10836
	200 ft. control	10837
	300 ft. control	10838
6.	Pigtail, 12 volt systems only	10831
7.	Tie, nylon	



8.4 Quantum Manual Metering Valve, Figure 18


Item	Description	Stock No.
(-)	Quantum metering valve w/wye	
*	Service kit, metering assembly (Fig.	18a)22854
1.	Upper body	21314
2.	Screw, 3/8-NC x 1" socket head	22655
3.	Lower body	22621
4.	Inspection plate	
5.	Screw, 1/4-NC x 3/4" hex head cap.	03052
6.	Nut, 1/4-NC wing	03113
7.	Housing, knob	22761
8.	Nut, knob housing	22762
9.	Metering plate and shaft	22763
10.	Metering screw	
11.	Knob, adjustment	

12.	Screw, 5/16-NC x 3/4" socket head22767	,
13.	Wye, 1-1/4"01818	3
14.	Nipple, 1-1/2" x 2" heavy wall01840)
15.	Nipple, 1-1/4" x 5-1/2"01874	ŀ



22854 Service Kit Quantum Metering Assembly


Item	Qty	Description
1.	1	Flange gasket
2.	1	Wiper seal
3.	1	O-ring, 3/4" OD nominal
4.	1	O-ring, 5/8" OD nominal
5.	2	O-ring 1-1/2" ID nominal
6.	1	Roll Pin



8.5	Millennium Valve Service Kit	22899
	Includes the following four service kits shown in	Sections
	8.6 and 8.7: 22856, 22898, 22857, and 22868	}

8.6 Millennium Valve, Inlet Segment, Figure 19


Item	Description	Stock No.
*	Service kit, inlet seals (Fig. 19a)	22856
**	Service kit, plunger tip (Fig. 19b)	22898
1.	Plunger	22600
2.	Dual piston	
3.	Spring, 4" long	22604
4	Screw, socket, w/internal threads	
5.	Sleeve, cylinder	22603
6.	Screw, 5/16-NC x 1-1/4", socket head	22611
7.	Body, inlet valve	21338
8.	Cap, cylinder	21339
9.	Plug, 1-1/2" NPT	02477
10.	Nipple, 1/4" NPT hex	02808
11.	Elbow, 1/4" NPT 90° female	06373
12.	Petcock, 1/4" NPT	01993
13.	Adaptor, 1/8" NPT w/1/16" orifice	01945
14.	Bushing, 1/4" x 1/8" brass	02010
15.	Adaptor, 1/4" NPT	02494
16.	Plug, 1-1/4" NPT	01762



22856 Service Kit Millennium Inlet Segment Seals


Refer to owners manual for service instruction.

Qty	Description
2	O-ring, 2-1/8" OD, nominal
1	U-seal, dual piston lower, 3-1/2" ID
1	U-seal, dual piston upper, 2-3/8" ID
1	O-ring, 4-1/8" OD, nominal
1	O-ring, 31/64" ID, nominal
1	Gasket, cylinder cap
	2 1 1




22898 Service Kit Millennium Plunger Tip

Item Qty	Description
1. 1	Screw, 5/16-NC button head
2. 1	Washer, plunger tip
3. 1	Tip, replaceable plunger



8.7 Millennium Valve Outlet Segment, Figure 20


Item	Description	Stock No.
*	Service kit, outlet segment (Fig. 20a)	22857
**	Service kit, muffler (Fig. 20b)	22868
1.	Sleeve, inner	22612
2.	Piston	22613
3.	Housing, muffler, 2 required	21346
4.	Valve body, exhaust	21345



22857 Service Kit Millennium Outlet Segment


Refer to owners manual for service instruction.

Item	Qty	Description
1.	1	O-ring, 1-5/8" ID nominal
2.	1	Diaphragm
3.	1	U-seal, piston
4.	2	O-ring, 3" ID nominal
5.	1	O-ring, 2-7/16" ID nominal
6.	4	Cap screw, 5/16-NC x 1"
7	4	Lock-washer 5/16"




22868 Service Kit Millennium Outlet Muffler

Item	Qty	Description
1.	2	Muffler element
2.	2	Liner, perforated rubber
3.	2	Screen
4.	6	Screw, 12 x 1"




8.8 Abrasive Trap, Figure 21

Item	Description	Stock No.
(-)Abra	sive trap	
*	Service kit, abrasive trap (Fig. 21a)	01925
1.	Cap	02014
2.	Body	02015
3.	Lock bar	02016
4.	Screw, 3/8-NC x 1" thumb	03289
5.	Shoulder screw, 3/8" x 3/8"	03291




01925 Service Kit Abrasive Trap

Item	Qty	Description
1.	3	Screen
2.	2	O-Ring
3.	1	Gasket, screen, 1/8" thick
4	1	Decal "clean screen"



Control Panel, Figure 22	
Description	Stock No.
Panel, control	
12 volt	07677
120 volt	07676
Filter, 1/4" w/ auto drain	05617
Lubricator (antifreeze injector) 1/4"	05616
Solenoid, 3- way	
12 volt AC	07662
12 volt DC	07664
Transformer (120 volt only)	02198
Supply cord, 5-ft.	
120 volt AC, w/15 amp twist-lock plu	ug02216
12 volt DC, w/lo-profile connector	-
Lead cord, 5-ft. w/ lo-profile connector	r10834
Tubing, 1/4" white poly, specify ft. req	
	Panel, control 12 volt

8.	Tubing, 1/4" orange poly, specify ft. reqd05615
9.	Tubing, 1/4" green poly, specify ft. reqd05614
10.	Nipple, 1/4" hex02808
11.	Coupling, 1/4" bulkhead05605
12.	Elbow, 1/4" NPT x 1/4" compression03428
13.	Connector, 1/8" NPT x 1/4" compression03430
14.	Adaptor, bulkhead 1/8" NPT x 3/16" hose .03432
15.	Fitting, exhaust03438
16.	Adaptor, 1/4" NPT02494
17.	Elbow, 1/4" brass street02027
18.	Connector, lo-profile, male10828
19.	Connector, lo-profile, female10829
20.	Plug, 15 amp twist-lock02275
21.	Connector, 1/2" strain relief02213
22.	Locknut, 1/2" conduit12713
23.	Fuse, 2 amp (120 volt only)03039
	• • • • • • • • • • • • • • • • • • • •



8.10 RLX Electric Control Handle, Figure 23

Item	Description	Stock No.
(-)	RLX Electric Control Handle	
	w/ Lo-Profile connector	10840
1.	Handle lever	10573
2.	Body	10568
3.	Lever lock	10564
4.	Clamp, switch cord, 2 required	05810
5.	Spring, lever 2 required	05823
6.	Switch with cord	05813
7.	Screw, 8-32 x3/8" rd. hd., 4 required	05814
8.	Nut, 8-32 lock, ss, 2 required	05815
9.	Spacer washer, stainless steel, 4 req	rd 05434
10.	Screw, 3/16" x 1-1/4" shoulder, 2 requ	d 05817
11.	Screw, 4-40 x 3/8" fillister head, 2 rec	rd 05818
12.	Tie, nylon	02195
13.	Connector, Lo-Profile	10828

